




Montagehandleiding / Assembly instructions /  
Montageanleitung / Les instructions d'installation  
42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)




A1=145x145x2445 (4x)



A2=145x145x2445 (2x)



B1=45x145x3198 (4x)




B2=45x145x3680 (2x)




B3=45x145x750 (12x)




C1=45x120x3770 (9x)



C2=45x145x2439 (18x)



C3=45x145x492 (4x)




C4=45x95x150 (16x)



D1=18x165x3346 (60x)



E1=25x195x2495 (4x)



E2=16x140x2456 (4x)



Optie 2 / Option 2:  
18x165x4908 (30x)  
18x165x1783 (30x)



T1=6x160 (70x)



T2=6x100 (26x)



S1=6x160 (28x)




S2=6x100 (34x)




S3=6x60 (62x)



S4=5x40 (670x)



SP1=Ø6 (1x)









SP2=Ø20 (1x)



SP3=Ø3.5 (1x)




TX 25/30 (1x)












1.



2.




Beton/Concrete





Montagehandleiding / Assembly instructions /  
 Montageanleitung / Les instructions d'installation  
 42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)



1.



Montagehandleiding / Assembly instructions /  
Montageanleitung / Les instructions d'installation  
42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)




Montagehandleiding / Assembly instructions /  
 Montageanleitung / Les instructions d'installation  
 42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)










3.






Montagehandleiding / Assembly instructions /  
Montageanleitung / Les instructions d'installation  
42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)

4.






5.




Montagehandleiding / Assembly instructions /  
 Montageanleitung / Les instructions d'installation  
 42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)



6.





7.







8.




9.






DETAIL P



DETAIL R




10.







11.




T1 (TX30)






DETAIL T





DETAIL U





12.



13.




Optie 2 / Option 2





14.



Montagehandleiding / Assembly instructions /  
Montageanleitung / Les instructions d'installation  
42.7925 - Zadeldak Hamar XL 6800x4500x3600mm (bxdxh)